

# **4 TIER GREENHOUSE**

**Model** 96909

# **ASSEMBLY AND OPERATION INSTRUCTIONS**



Diagrams within this manual may not be drawn proportionally.

Due to continuing improvements, actual product may differ slightly from the product described herein.

Distributed exclusively by Harbor Freight Tools<sup>®</sup>.

3491 Mission Oaks Blvd., Camarillo, CA 93011

Visit our website at: http://www.harborfreight.com



Read this material before using this product. Failure to do so can result in serious injury. SAVE THIS MANUAL.

Copyright<sup>©</sup> 2007 by Harbor Freight Tools<sup>®</sup>. All rights reserved. No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools.

For technical questions or replacement parts, please call 1-800-444-3353.

#### **Save This Manual**

You will need this manual for the safety warnings and precautions, assembly, operating, inspection, maintenance and cleaning procedures, parts list and assembly diagram. Keep your invoice with this manual. Write the invoice number on the inside of the front cover. Write the product's serial number in the back of the manual near the assembly diagram, or write month and year of purchase if product has no number. Keep this manual and invoice in a safe and dry place for future reference.

#### **GENERAL SAFETY RULES**

- 1. Keep your work area clean and well lit. Cluttered and dark areas invite accidents.
- 2. Children should never be left unattended around the Mini Greenhouse or allowed to play with it, as it poses a potential suffocation danger.
- 3. Do not force the unit to perform outside of it's capabilities. Use the correct product for your application. Do not use the Mini Greenhouse for a purpose for which it is not intended.
- 4. Store idle products out of reach of children and other untrained persons. This item can be dangerous in the hands of untrained users.
- 5. Maintain labels on the product. These carry important information. If unreadable or missing, contact Harbor Freight Tools for a replacement.
- 6. Maintain a safe working environment. Make sure there is adequate surrounding workspace.
- 7. Do not exceed the maximum shelf capacity of 20 Pounds. Exceeding maximum shelf capacity can damage the Mini Greenhouse and create a safety hazard.

## **UNPACKING**

When unpacking, check to make sure that the item is intact and undamaged. If any parts are missing or broken, please call Harbor Freight Tools at the number shown on the cover of this manual as soon as possible.

## **ASSEMBLY INSTRUCTIONS**

**Note:** For additional information regarding the parts listed in the following pages, refer to the Assembly Diagram at the end of the manual.

1. Insert 3 Horizontal Rods (B) into the Connectors (A) and place the Shelf on top of the Horizontal Rods. Please note: shelves should be installed so that wire web and rivets are facing up.

- 2. Insert a Vertical Rod (C) into each corner of the Connector (A) on each side.
- 3. Place a Connector on top of the Vertical Rods, connect the Horizontal Rods, and place a Shelf on top of them.
- 4. Repeat until the top tier is reached.
- 5. Insert the two Arches (D) on top of the Connectors.
- 6. Slide Cover (F) over top of entire assembly.
- Once assembled, make sure all connections are secure and that the Mini Greenhouse rests squarely on a firm, level surface capable of bearing the combined weight of the Mini Greenhouse and it's contents. Place plants or seedlings in Mini Greenhouse carefully and distribute weight evenly. Do not exceed the 20 pound maximum weight capacity.

#### INSPECTION, MAINTENANCE, AND CLEANING

- 1. Before each use, inspect the general condition of the Mini Greenhouse. Check to assure connections are tight and secure and that there are no cracked or broken parts. <u>Do not use damaged equipment.</u>
- 2. To clean: Wipe with a damp cloth using a mild detergent.

## PLEASE READ THE FOLLOWING CAREFULLY

THE MANUFACTURER AND/OR DISTRIBUTOR HAS PROVIDED THE PARTS LIST AND ASSEMBLY DIAGRAM IN THIS MANUAL AS A REFERENCE TOOL ONLY. NEITHER THE MANUFACTURER OR DISTRIBUTOR MAKES ANY REPRESENTATION OR WARRANTY OF ANY KIND TO THE BUYER THAT HE OR SHE IS QUALIFIED TO MAKE ANY REPAIRS TO THE PRODUCT, OR THAT HE OR SHE IS QUALIFIED TO REPLACE ANY PARTS OF THE PRODUCT. IN FACT, THE MANUFACTURER AND/OR DISTRIBUTOR EXPRESSLY STATES THAT ALL REPAIRS AND PARTS REPLACEMENTS SHOULD BE UNDERTAKEN BY CERTIFIED AND LICENSED TECHNICIANS, AND NOT BY THE BUYER. THE BUYER ASSUMES ALL RISK AND LIABILITY ARISING OUT OF HIS OR HER REPAIRS TO THE ORIGINAL PRODUCT OR REPLACEMENT PARTS THERETO, OR ARISING OUT OF HIS OR HER INSTALLATION OF REPLACEMENT PARTS THERETO.

Record Product's Serial Number Here	1.
iteedia i ioaact 3 ociiai italiibei iiele	' =

**Note:** If product has no serial number, record month and year of purchase instead.

**Note:** Some parts are listed and shown for illustration purposes only, and are not available individually as replacement parts.

# PARTS LIST & ASSEMBLY DIAGRAM

Part	Description	Qty
А	Connector	10
В	Horizontal Rod	12
С	Vertical Rod	16

	Part	Qty
Α		10
В		12
С		16
D		2
Ε		4
F		1

Part	Description	Qty
D	Arch	2
Е	Shelf	4
F	Cover	1

